

THE BLIND SHOP

Instructions

Somfy Remote Control Programming for Cassette & Side Track Roller Blinds

Note: Follow instructions carefully to ensure motor is programmed correctly.

Programming Upper and Lower Limit Positions

1. 'Wake up' the motor by plugging in the charger. The blind will 'jog' (move up and down briefly).
2. Press the UP and DOWN buttons simultaneously until the blind jogs again.
3. Check the direction of the UP and DOWN buttons. Press the DOWN button. The blind should go down. To change direction press and hold the MY button until the blind jogs.
4. Use the UP and DOWN buttons to position the blind so that it is at the desired upper limit/fully open position.
5. Briefly press and release the MY and DOWN buttons simultaneously. The blind will lower. When the blind is approximately at the lower limit/fully closed position press the MY button to stop the blind.
6. Use the UP and DOWN buttons to position the blind so that it is exactly at the desired lower limit/fully closed position.
7. Briefly press and release the MY and UP buttons simultaneously. The blind will move up and stop at the programmed upper limit/fully open position.
8. To confirm both limits press the MY button until the blind jogs.
9. Briefly press and release the PROGRAMME button on the back of the handset (using a sharp pencil or paper clip). The blind will jog. Your programming has been recorded.



Programming the favourite 'My' Position

1. Press the UP and DOWN buttons to move the blind to the desired position.
2. Press and hold the MY button for approximately 5 seconds until the blind jogs. Your 'My' position has been recorded.

Factory Reset

To erase all programming, press and hold the programme button on the motor head (for approximately 15 seconds) until the blind jogs 3 times. Only release the button after the 3rd jog. Some motors have a translucent plastic button and some have a recessed button located in a small hole that will need to be pressed with a paperclip.

Troubleshooting

Call the Somfy Helpline on 01 13 391 3030 and select option 1.

THEBLINDSHOP.COM

The Blind Shop Ltd, Unit 5 Lady Bee Studios, Riverside, Brighton, West Sussex BN42 4BY
01273 462196 info@theblindshop.com

Reg address: Maria House, 35 Millers Road, Brighton, East Sussex BN1 5NP Reg no. 5960311 VAT no. 896801771

